

# INFORMATION OM EKODESIGN

www.sodeca.com

Enligt kommissionens förordning (EU) 2024/1834 om genomförande av Europaparlamentets direktiv 2009/125/EG

SODECA, S.L.U.

- a) fläkttyp

b) fläktverkningsgrad [%]

c) VSD antagen i data

d) mätkategori
- e) verkningsgradskategori

f) N fan

g1) Pe [kW]

g2) qv [m³/h]
- g3) Δp [Pa]

h1) fläkt för dubbla användningsområden

h2) reversibel fläkt

h3) fläkt med låg ljudnivå
- i) likspänning under 100 V

k) σBEP

l) fläkthastighet [rpm]

m) specifikt förhållande
- j) p) q) väsentliga delar, information om demontering och återvinning i produktmanualen

| Modell                        | a) | b) | c) | d) | e) | f) | g1) | g2) | g3) | h1)                | h2) | h3) | i) | k) | l) | m) |
|-------------------------------|----|----|----|----|----|----|-----|-----|-----|--------------------|-----|-----|----|----|----|----|
| HTMV/ATEX-40-4T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-40-6T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-45-4T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-45-6T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-50-4T-1/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-50-6T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-1/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-1.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-2/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-56-6T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-1.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-2/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-3/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-4/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-63-6T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-63-6T-1/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-2/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-3/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-4/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-0.75/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-1/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-1.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-4T-4/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-4T-5.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-1.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-2/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-3/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-5.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-7.5/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-10/2G Ex eb   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-2/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-3/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-4/2G Ex eb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-7.5/2G Ex eb |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-10/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-15/2G Ex eb  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |

## INFORMATION OM EKODESIGN

www.sodeca.com

Enligt kommissionens förordning (EU) 2024/1834 om genomförande av Europaparlamentets direktiv 2009/125/EG

SODECA, S.L.U.

| Modell                          | a) | b) | c) | d) | e) | f) | g1) | g2) | g3)                | h1) | h2) | h3) | i) | k) | l) | m) |
|---------------------------------|----|----|----|----|----|----|-----|-----|--------------------|-----|-----|-----|----|----|----|----|
| HTMV/ATEX-100-4T-20/2G Ex eb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-3/2G Ex eb     |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-4/2G Ex eb     |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-5.5/2G Ex eb   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-25/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-30/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-40/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-50/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-25/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-30/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-40/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-50/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-5.5/2G Ex eb |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-7.5/2G Ex eb |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-10/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-15/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-20/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/9-10/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/9-15/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/9-20/2G Ex eb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-40-4T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-40-6T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-45-4T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-45-6T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-50-4T-1/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-50-6T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-1/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-1.5/2G Ex db    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-2/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-56-6T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-1.5/2G Ex db    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-2/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-3/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-4/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-6T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-6T-1/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-2/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-3/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-4/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-0.75/2G Ex db   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-1/2G Ex db      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-1.5/2G Ex db    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |

## INFORMATION OM EKODESIGN

www.sodeca.com

Enligt kommissionens förordning (EU) 2024/1834 om genomförande av Europaparlamentets direktiv 2009/125/EG

SODECA, S.L.U.

| Modell                          | a) | b) | c) | d) | e) | f) | g1) | g2) | g3) | h1)                | h2) | h3) | i) | k) | l) | m) |
|---------------------------------|----|----|----|----|----|----|-----|-----|-----|--------------------|-----|-----|----|----|----|----|
| HTMV/ATEX-80-4T-4/2G Ex db      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-4T-5.5/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-1.5/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-2/2G Ex db      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-3/2G Ex db      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-5.5/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-7.5/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-10/2G Ex db     |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-2/2G Ex db      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-3/2G Ex db      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-4/2G Ex db      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-7.5/2G Ex db   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-10/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-15/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-20/2G Ex db    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-3/2G Ex db     |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-4/2G Ex db     |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-5.5/2G Ex db   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-25/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-30/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-40/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-50/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-25/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-30/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-40/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-50/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-5.5/2G Ex db |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-7.5/2G Ex db |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-10/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-15/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-20/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/9-10/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/9-15/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/9-20/2G Ex db  |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-40-4T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-40-6T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-45-4T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-45-6T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-50-4T-1/2D Ex tb      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-50-6T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-1/2D Ex tb      |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |
| HTMV/ATEX-56-4T-1.5/2D Ex tb    |    |    |    |    |    |    |     |     |     | ErP: Uteslut. ATEX |     |     |    |    |    |    |

## INFORMATION OM EKODESIGN

www.sodeca.com

Enligt kommissionens förordning (EU) 2024/1834 om genomförande av Europaparlamentets direktiv 2009/125/EG

SODECA, S.L.U.

| Modell                          | a) | b) | c) | d) | e) | f) | g1) | g2) | g3)                | h1) | h2) | h3) | i) | k) | l) | m) |
|---------------------------------|----|----|----|----|----|----|-----|-----|--------------------|-----|-----|-----|----|----|----|----|
| HTMV/ATEX-56-4T-2/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-56-6T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-1.5/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-2/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-3/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-4T-4/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-6T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-63-6T-1/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-2/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-3/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-4T-4/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-0.75/2D Ex tb   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-1/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-71-6T-1.5/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-80-4T-4/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-80-4T-5.5/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-1.5/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-2/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-80-6T-3/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-5.5/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-7.5/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-90-4T-10/2D Ex tb     |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-2/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-3/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-90-6T-4/2D Ex tb      |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-7.5/2D Ex tb   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-10/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-15/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-4T-20/2D Ex tb    |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-3/2D Ex tb     |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-4/2D Ex tb     |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-100-6T-5.5/2D Ex tb   |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-25/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-30/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-40/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/6-50/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-25/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-30/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-40/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-4T/9-50/2D Ex tb  |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-5.5/2D Ex tb |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |
| HTMV/ATEX-125-6T/6-7.5/2D Ex tb |    |    |    |    |    |    |     |     | ErP: Uteslut. ATEX |     |     |     |    |    |    |    |

INFORMATION OM EKODESIGN

Enligt kommissionens förordning (EU) 2024/1834 om genomförande av Europaparlamentets direktiv 2009/125/EG

SODECA, S.L.U.

| Modell                         | a) | b) | c) | d) | e) | f) | g1) | g2) | g3) | h1) | h2) | h3) | i) | k) | l) | m)                 |
|--------------------------------|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|----|----|----|--------------------|
| HTMV/ATEX-125-6T/6-10/2D Ex tb |    |    |    |    |    |    |     |     |     |     |     |     |    |    |    | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-15/2D Ex tb |    |    |    |    |    |    |     |     |     |     |     |     |    |    |    | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-20/2D Ex tb |    |    |    |    |    |    |     |     |     |     |     |     |    |    |    | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-10/2D Ex tb |    |    |    |    |    |    |     |     |     |     |     |     |    |    |    | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-15/2D Ex tb |    |    |    |    |    |    |     |     |     |     |     |     |    |    |    | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-20/2D Ex tb |    |    |    |    |    |    |     |     |     |     |     |     |    |    |    | ErP: Uteslut. ATEX |